



Through only one Control Panel (Display) it's possible to manage more than one Cold Air evaporative cooler connecting into the system one or more Router Module.

The system is composed of:

1 Display

1 Cold Air evaporative cooler as Master

Until 4 Cold Air evaporative coolers as Client for each Router (max 3 Routers)

### Notes

Only the Display can feels temperature and U.R. of the environment so you'll have to think it over when you're studying the right number and the position of the coolers

The max distance between Router and the cooler is 200 mt.

Example of connections (1 Router (max 5 coolers) – 2 Routers (max 9 coolers) – 3 Routers (max 13 coolers))

